

端子台仕様【配線用遮断器】

●表中の図は、表面形配線用遮断器の、内部付属装置を、遮断器本体の左右いずれかの側から引き出すかを示したものです。裏面形・埋込形については加工が必要ですので別途お問い合わせください。

 : ON・OFF操作ハンドルを示します。

タイプ	適用器種	AX⊗ (補助スイッチ)	AL□ (警報スイッチ)	SHT⊕ (電圧引外し装置)	UVT⊙ (不足電圧引外し装置)	AX⊗ + AL□	AX⊗ + SHT⊕	AL□ + SHT⊕	AX⊗ + AL□ + SHT⊕	AX⊗ + AL□ + UVT⊙
Eシリーズ (経済タイプ)	B-32EB B-52EB B-62EB	 ⊗	 □	 ⊕			 ⊗  ⊕	 □  ⊕		
	B-33MEA、M-3BA B-33EA B-53EA B-63EA	 ⊗	 □	 ⊕		 □  ⊗	 ⊗  ⊕	 □  ⊕	 □  ⊗  ⊕	
	B-102EA・103EA B-122EA・123EA B-152EA・153EA	 ⊗	 □	 ⊕		 ⊗  □	 ⊗  ⊕	 □  ⊕	 ⊗  □  ⊕	
	B-222EA・223EA B-252EA・253EA	 ⊗	 □	 ⊕		 ⊗  □	 ⊗  ⊕	 □  ⊕	 ⊗  □  ⊕	
	B-402EA・403EA	 ⊗	 □	 ⊕		 ⊗  □	 ⊗  ⊕	 □  ⊕	 ⊗  □  ⊕	
	B-602EA・603EA	 ⊗	 □	 ⊕	 ⊙	 □  ⊗	 ⊕  ⊗	 □  ⊕	 ⊕  □  ⊗	 ⊙  □  ⊗
Sシリーズ (汎用タイプ)	B-52S・53S B-62S・63S	 ⊗	 □  ⊕	 ⊕		 □  ⊗	 ⊗  ⊕	 □  ⊕		
	B-102S・103S B-222S・223S	 ⊗  ⊕	 □  ⊕	 ⊕		 □  ⊗	 ⊗  ⊕	 □  ⊕	 ⊗  □  ⊕	
Fシリーズ (高遮断容量 タイプ)	B-32FB B-62FA	 ⊗	 □	 ⊕		 □  ⊗				
	B-33FB B-63FA	 ⊗	 □	 ⊕		 □  ⊗	 ⊕  ⊗	 □  ⊕	 ⊕  □  ⊗	 ⊙  □  ⊗
	B-52FEA、B-52FD B-52FKA B-102FB、B-102FKA	 ⊗	 □	 ⊕		 □  ⊗				
	B-53FEA B-53FD・54FC B-53FKA・54FKA B-103FB B-103FKA・104FKA	 ⊗	 □	 ⊕	 ⊙ B-53FD不可 B-53FEA不可	 □  ⊗	 ⊕  ⊗	 □  ⊕	 ⊕  □  ⊗	 ⊙  □  ⊗
	B-222FB・223FB ・224FB	 ⊗	 □	 ⊕	 ⊙	 □  ⊗	 ⊕  ⊗	 □  ⊕	 ⊕  □  ⊗	 ⊙  □  ⊗
	B-402FB・403FB ・404FB	 ⊗	 □	 ⊕	 ⊙	 □  ⊗	 ⊕  ⊗	 □  ⊕		
	600Aフレーム 4000Aフレーム	 ⊗	 □	 ⊕	 ⊙	 □  ⊗	 ⊕  ⊗	 □  ⊕	 ⊕  □  ⊗	 ⊙  □  ⊗
電子式 配線用遮断器	B-223WA B-403WA	 ⊗	 □	 ⊕	 ⊙	 □  ⊗	 ⊕  ⊗	 □  ⊕	 ⊕  □  ⊗	 ⊙  □  ⊗
	B-603WA B-803WB・804WA	 ⊗	 □	 ⊕	 ⊙	 □  ⊗	 ⊕  ⊗	 □  ⊕	 ⊕  □  ⊗	 ⊙  □  ⊗
	1000Aフレーム 3200Aフレーム	 ⊗	 □	 ⊕	 ⊙	 □  ⊗	 ⊕  ⊗	 □  ⊕	 ⊕  □  ⊗	 ⊙  □  ⊗
分電盤 協約形サイズ	B-32KA、B-52MKA B-52KA、B-62KA B-102KA	 ⊗	 □	 ⊕			 ⊗  ⊕	 □  ⊕		
	B-33KA、B-53KA B-63KA、B-103KA M-33KA、M-53KA	⊗	□	⊕		□ ⊗	⊗ ⊕	□ ⊕	□ ⊗ ⊕	
単3中性線 欠相保護付 配線用遮断器	BU-53・1J BU-63・1J	⊗	□			□ ⊗				
	BU-53・1KA BU-63・1KA BU-103・1KA	⊗ ⊕	□ ⊕			□ ⊗				
	BU-123・1EA BU-153・1EA BU-223・1EA BU-253・1EA BU-403・1EA	⊗	□			⊗ □				
耐熱形	FB-52B・53B FB-103A FB-223A FB-403A	⊗	□							